GASTEC Instructions for Chlorine Detector Tube

FOR SAFE OPERATION:

Read this manual and the instruction manual of your Gastec Gas Sampling Pump carefully.

⚠ WARNING :

- 1. Use only Gastec detector tubes in a Gastec pump.
- 2. Do not interchange or use non-Gastec parts or components in Gastec's detector tube and pump system.
- 3. The use of non-Gastec parts or components in Gastec's detector tube and pump system or use of a non-Gastec detector tube with a Gastec pump or use of a Gastec detector tube with a non-Gastec pump may result in property damage, serious bodily injury, and death; voids all warranties; and voids all performance and data accuracy guaranties.

△ CAUTION : If not observed, injuries to the operator or damage to the product may result.

- 1. When breaking the tube ends, keep away from eyes.
- 2. Do not touch the broken glass tubes, piece and reagent with bare hand(s).
- 3. The sampling time represents the time necessary to draw the air sample through the tube. The tube must be positioned in the desired sampling area for the entire sampling time or until the flow finish indicator indicates the end of the sample.

\triangle NOTES: For maintaining performance and reliability to the test results.

- Use Gastec Gas Sampling Pump together with Gastec Detector Tubes only for the purposes specified in the instruction manual of the detector tube.
- 2. Use this tube under the temperature range of $0 40^{\circ}\text{C}$ (32 104°F).
- 3. Use this tube under the relative humidity range of 0 90%.
- 4. This tube may be interfered with by the coexisting gases. Please refer to the "INTERFERENCES".
- 5. Shelf life and storage condition of the tube are marked on the label of the box of tube.

APPLICATION OF THE TUBE: Use of this tube for the detection of Chlorine in air or the industrial areas and environmental atmospheric condition.

SPECIFICATION: (As a result of Gastec's commitment to continued improvement, specifications are subject to change without notice.)



Detecting Layer

Measuring Range	0.1 - 0.5 ppm	0.5 - 8 ppm	8 - 16 ppm	
Number of Pump Strokes	2 - 5	1	1/2	
Correction Factor	1/2 - 1/5	1	2	
Sampling Time	1 minute per pump stroke		30 seconds	
Detecting Limit	0.05 ppm (n = 5)			
Color Change	White → Pale pink			
Reaction Principle	Chlorine reacts with 3,3,5,5-Tetramethylbendizine (Indicator) to			
	produce pale pink sta	ain.		
	Cl₂ + 3,3,5,5-Tetramethylbendizine → Pale pink stain			

Coefficient of Variation: 10% (for 0.5 to 2 ppm), 5 % (for 2 to 8 ppm)

- ** Shelf Life: Please refer to the Validity Date printed on the box of tube.
- ** Store the tubes in dark and cool place.

CORRECTION FOR TEMPERATURE, HUMIDITY AND PRESSURE:

Calibration of other Gastec detector Tube No.8La is based on a tube temperature of 20°C (68°F) and not the temperature of the gas being sampled, approximately 50% relative humidity and normal atmospheric pressure.

Temperature: No correction is required. **Humidity:** No correction is required.

Pressure: To correct for pressure, multiply by the tube reading by

Tube Reading (ppm) × 1013 (hPa)
Atmospheric Pressure (hPa)

MEASUREMENT PROCEDURE:

- For leak checking of the pump insert a fresh sealed detector tube into pump. Follow instructions provided with the pump operation manual.
- 2. Break tips off a fresh detector tube in the tube tip breaker of the pump.
- 3. Insert the tube into the pump inlet with arrow (G>) on the tube pointing toward pump.
- 4. Make certain pump handle is all the way in. Align guide marks on pump body and handle.
- Pull handle all the way out until it locks on 1 pump stroke (100ml). Wait 1 minute and confirm the completion of the sampling.
- For lower than 0.5 ppm measurement, repeat the above sampling procedure up to 4 more times until the stain attains to the first calibration mark. For higher than 8 ppm measurement, prepare fresh tube and take 1/2 pump stroke.
- 7. Read concentration at the interface of the stained-to-unstained reagent.
- 8. If correction is needed, multiply the correction factors of pump strokes and pressure.

INTERFERENCES:

Substance	Interference	Changes color by itself to	
Nitric oxide	Plus error	Pale pink	
Ozone	Plus error	Pale pink	
Nitrogen dioxide	Plus error	Pale pink	
Chlorine dioxide	Plus error	Pale pink	
Bromine, Iodine	Plus error	Pale pink	

The table of this interference gases primarily expresses the interference of each coexisting gas in the concentration range, equivalent to the gas concentration. Therefore, the test result may be given positive result by the other substances not listed in the table. For more information is needed, please contact us or our distributors in your territory.

APPLICATION FOR OTHER SUBSTANCES:

Tube 8La can also be used for other substances as below:

Substance	Correction Factor	No. of Pump Strokes	Measuring Range
Bromine	0.1	4	0.05 - 0.8 ppm

CORRECTION FACTOR: Detector tubes are primarily designed to measure specific gases. But it is also possible to measure other substances of similar chemical properties with the aid of a correction factor or chart. Therefore, please make use of the correction factor/chart measuring ranges as a reference. For more precise factor please contact your Gastec disfributor.

DANGEROUS AND HAZARDOUS PROPERTIES:

Threshold Limit Value-Time Weighted Average by ACGIH (2004): 0.5 ppm Threshold Limit Value-Short Term Exposure Limit by ACGIH (2004): 1 ppm

DISPOSAL INSTRUCTION: Reagent of the tube does not use toxic substances. When disposing the tube regardless of whether used or unused, follow the rules and regulations of the local government.

WARRANTY: If you have any questions regarding gas detection and quality of the tubes, please feel free to contact your Gastec representatives.

IM008LaE4

Manufacturer: Gastec Corporation 6431 Fukaya, Ayase-City, 252-1103, Japan

04l1Z

Printed in Japan