

GASTEC Instructions for No.5Lb Sulfur Dioxide Detector Tube

FOR SAFE OPERATION :

Read this manual and the instruction manual of your Gastec Gas Sampling Pump carefully.

⚠ WARNING :

1. Use only Gastec detector tubes in a Gastec Pump.
2. Do not interchange or use non-Gastec parts or components in Gastec's detector tube and pump system.
3. The use of non-Gastec parts or components in Gastec's detector tube and pump system or use of a non-Gastec detector tube with a Gastec pump or use of a Gastec detector tube with a non-Gastec pump may result in property damage, serious bodily injury, and death; voids all warranties; and voids all performance and data accuracy guaranties.

⚠ CAUTION : If not observed, injuries to the operator or damage to the product may result.


1. When breaking the tube ends, keep away from eyes.
2. Do not touch the broken glass tubes, pieces and reagent with bare hand(s).
3. The sampling time represents the time necessary to draw the air sample through the tube. The tube must be positioned in the desired sampling area for the entire sampling time or until the flow finish indicator indicates the end of the sample.

△ NOTES : For maintaining performance and reliability of the test results.

1. Use Gastec Gas Sampling Pump together with Gastec Detector Tubes only for the purposes specified in the instruction manual of the detector tube.
2. Use this tube within the temperature range of 0 - 40°C (32 - 104°F).
3. Use this tube within the relative humidity range of 20 - 80%.
4. This tube may be interfered with by the coexisting gases. Please refer to the "INTERFERENCES".
5. If this tube samples the steel cylinder gas containing nitrogen or sulfur hexafluoride or water vapor concentration of less than 0.1 mg/l or 100% of Carbon dioxide gas of 200 ml or more, the tube shows faint yellowish discoloration from the gas inlet of the tube.
6. Shelf life and storage conditions of the tube are marked on the label of the box of tube.

APPLICATION OF THE TUBE : Use of this tube for the detection of Sulfur dioxide in air or the industrial areas and environmental atmospheric condition.

SPECIFICATION : (As a result of Gastec's commitment to continued improvement, specifications are subject to change without notice.)



Measuring Range	0.05 - 0.1 ppm	0.1 - 0.2 ppm	0.2 - 5.0 ppm	5.0 - 10.0ppm
Number of Pump Strokes	8	4	2	1
Correction Factor	1/4	1/2	1	2
Sampling Time	1 minute per pump stroke			
Detecting Limit	0.01 ppm (n=8)			
Color Change	Yellowish green → Yellow			
Reaction Principle	Sulfur dioxide reacts with barium chloride to generate hydrogen chloride to discolor the indicator to yellow. $\text{SO}_2 + \text{BaCl}_2 + \text{H}_2\text{O} \rightarrow \text{BaSO}_3 + 2\text{HCl}$ $\text{HCl} + \text{Base} \rightarrow \text{Chlorides}$			

Coefficient of Variation : 10% (for 0.2 to 1 ppm), 5% (for 1 to 5 ppm)

**** Shelf Life :** Please refer to the Validity Date printed on the box of tube.

**** Store the tubes in dark and cool place.**

CORRECTION FOR TEMPERATURE, HUMIDITY AND PRESSURE :

Calibration of the Gastec detector Tube No.5Lb is based on a tube temperature of 20°C (68°F) and not the temperature of the gas being sampled, approximately 50% relative humidity and normal atmospheric pressure.

Temperature : No correction is required.

Humidity : No correction is required.

Pressure : To correct for pressure, multiply the tube reading by

$$\frac{\text{Tube Reading (ppm)} \times 1013 \text{ (hPa)}}{\text{Atmospheric Pressure (hPa)}}$$

MEASUREMENT PROCEDURE :

1. For leak tight check of the pump insert a fresh sealed detector tube into pump. Follow instructions provided with the pump operating manual.
2. Break tips off a fresh detector tube in the tube tip breaker of the pump.
3. Insert the tube securely into pump inlet with arrow (➔) on the tube pointing toward pump.
4. Make certain pump handle is all the way in. Align guide marks on pump body and handle.
5. Pull handle all the way out until it locks on 1 pump stroke (100ml). Wait 1 minutes and confirm the completion of the sampling. Repeat the sampling procedure one more time.
6. For lower than 0.2 ppm measurement, repeat the above sampling procedure 2 or 6 more times until the stain attains to the first calibration mark. For higher than 5.0 ppm measurement, prepare fresh tube, and take 1 pump stroke.
7. Read concentration at the interface of the stained-to-unstained reagent.
8. If correction is needed, multiply the correction factors of pump strokes and pressure.

INTERFERENCES :

Substance	Concentration	Interference	Changes color by itself to
Carbon monoxide, Nitric oxide		No effect	No discoloration
Carbon dioxide	100%	Plus error	Yellow
Nitrogen dioxide	≥ 1 ppm	Unclear discoloration	Yellow
Hydrogen sulfide		No effect	No discoloration

The table of this interference gases primarily expresses the interference of each coexisting gas in the gas concentration range, equivalent to the gas concentration. Therefore, the test result may be given positive result by the other substances not listed in the table. For more information is needed, please contact us or our distributors in your territory.

DANGEROUS AND HAZARDOUS PROPERTIES :

Threshold Limit Value-Time Weighted Average by ACGIH (2004) : 2 ppm

Threshold Limit Value-Short Term Exposure Limit by ACGIH (2004) : 5ppm

DISPOSAL INSTRUCTION :

Reagents of the tube does not use toxic substances. When disposing of the tube regardless of whether used or unused, follow the rules and regulations of the local government.

WARRANTY : If you have any questions regarding gas detection and quality of the tubes, please feel free to contact your Gastec representatives.

Manufacturer : Gastec Corporation
6431 Fukaya, Ayase-City, 252-1103, Japan

IM005LbE2
Printed in Japan
0411Z