

## ORP Electrode

### Pulse Instruments Electrode Series

Item Number: PI0020-ORP

- High Performance
- Gel Sealed
- Porous Teflon Junction

#### High Performance Electrodes

Pulse offers a variety of electrodes to suit the needs of every application. The following electrodes feature a patented reference junction made of porous teflon that is more resistant to clogging problems than conventional materials, and offers a higher reference flow for a rapid and stable measurement.

Special PI0020 Series are electrodes specially designed with a high tolerance electrolyte for strong oxidizers such as chlorine. They are used in a flow cell in continuous measurement process environments.

12mm diameter body has a 15ft cable with a BNC connector and may be used with any pH or ORP meter that accept a BNC connection.

